

Rescue Procedure for the Fully Enclosed Lifeboat Kit



Approach the casualty upwind to form a lee. The final approach should be at slow speed. Lower the cradle into the water to allow the casualty to be floated into the scoop. The rescuers should be connected to the lifeboat with a life line and try to maintain a stable posture.



Once the cradle is central to the casualty's upper torso the lift may commence using the block and tackle. It is important not to jerk the casualty, so try to use a controlled pulling motion. The second rescuer can now assist with the lift.



Continue raising the cradle until it reaches the top of the post. Now the casualty is ready to be slewed into the doorway.



Push the cradle so that it pivots on its single fixing point, forming a chute for the casualty to be manoeuvred through the door. Once the casualty is inside and comfortable this procedure can be repeated.

Jason's Cradle® MOB systems

+44 (0)1202 874365

www.jasonscradle.co.uk

Manufactured by: Land and Marine Products Ltd

6 Aerial Park, Uddens Trading Estate, Wimborne, Dorset BH21 7NL T: +44 (0)1202 874365 F: +44 (0)1202 876296 E: info@jasonscradle.co.uk

Issue 1